

HHMPI, Interface Cables & Accessories		
Flight Recorder P/N	HHMPI & Cable P/N	Description
N/A	FDS40-0104	Multi Purpose Interface (MPI V3 Civil Variant)
N/A	FDS40-0301	Hand Held Multi-Purpose Interface (HHMPI) Kit *Includes HHMPI Cradle
N/A	FDS40-5102	HHMPI Engineering Unit conversion software
N/A	FDS40-0331	HHMPI PCMCIA Assembly
N/A	FDS40-0332	Wireless Capability Option
N/A	FDS40-0373	HHMPI Docking Cradle
Honeywell UFDR 980-4100-xxx	FDS40-0204	Honeywell DFDR (Sunstrand DFDR) UFDR, Interface Cable
	FDS40-0275	Honeywell AR FDR Interface Cable (45 foot length)
Honeywell SSFDR 980-4120-xxx 980-4700-xxx	FDS40-0203	Honeywell SSFDR Interface Cable
Honeywell (SRVIVR) 980-4131-xxx LW FDR 980-6050-xxx LW CVR 980-6044-XXX (LW CVDR)	FDS40-0210	Honeywell Light Weight (AR HFR5) Interface cable. Requires on-aircraft CVR download cable for insitu downloads
Honeywell SSFDR 980-4710-00X	FDS40-0208	Honeywell AR Series FDR Interface Cable
Honeywell HFR5-D 980-4750-009	FDS40-0232	Honeywell HFR5-D Interface Cable
Honeywell HFR5-V CVR 980-6032-001	FDS40-0274	Honeywell HFR5-V Interface Cable. Requires on-aircraft CVR download cable for insitu downloads
Honeywell SSCVR 980-6020-xxx 980-6022-xxx	FDS40-0216	Honeywell CVR Download and Power, Interface Cable (On-bench)
Honeywell DVDR 980-6025-001 (DVDR)	FDS40-0227	Honeywell DVDR, Interface Cable. Requires on-aircraft CVR download cable for insitu downloads
Lockheed 10077A500-803 FDR (L209)	FDS40-0205	Lockheed L209/Plessey 1584 Interface Cable
L3 Comm QAR	FDS40-0241	L3 Comm USB Cable
L3 Comm F1000 SSFDR S603, S703, S800, S903	FDS40-0201	L3 Comm. F1000, SSFDR Interface Cable
L3 Comm FDR, CVR, CVDR FA2100 / FA2200 / FA2300	FDS40-0202	L3 Comm. FA2100 CVDR Interface Cable. Requires on-aircraft CVR download cable for insitu downloads
L3 Comm SRVIVR 1493100-1XXXX CVR 1493100-2XXXX FDR 1493100-3XXX CVDR	FDS40-0209	L3 Comm. SRVIVR Interface Cable. Requires on-aircraft CVR download cable for insitu downloads
L3 Comm FDR & CVR FA5000 FDR & CVR	FDS40-0223	L3 Com. FA5000 Interface Cable. Requires on-aircraft CVR download cable for insitu downloads
Universal 1607 FDR 1606 CVR 1605 CVDR	FDS40-0224	UASC CVFDR Interface Cable. Requires on-aircraft CVR download cable for insitu downloads
BASE MCR500-xxx / SCR 500-xxx	FDS40-0212	BAe MCR500 Interface Cable
Penny & Giles MPFR D51615-XXX	FDS40-0271	MPFR Bench Download Cable
Penny & Giles 91005 (B&D/Spirent)D51615-XXX	FDS40-0270	B&D (Spirent) Interface Cable
On-Aircraft CVR Download Cables For CVR		
Flight Recorder P/N	Interface P/N	Description
Honeywell SSCVR 980-6020-XXX 980-6022-XXX	FDS40-0215	Honeywell CVR Rack Adaptor (On-aircraft)
Honeywell AR 980-6021-032 CVR 980-6021-066 CVR 980-6021-072 CVFDR 980-6021-083 CVFDR	FDS40-0246	Honeywell AR Series CVR/Combi Interface Cable (On-Aircraft)
Honeywell HFR5-V CVR 980-6032-001	FDS40-0247	ARINC-757 CVR Rack Adaptor. (L3 FA2100 and Honeywell HFR5-V CVR Aircraft Rack Adapter. On-Aircraft)
Honeywell SRVIVR 980-6050-xxx (LW CVR) 980-6044-XXX (LW CVDR)	FDS40-0259	Honeywell LW/SRVIVR CVR Power Cable (On-Aircraft)
L-3 Comm FA2100 CVR & CVDR FA2300 CVDR	FDS40-0247	ARINC-757 CVR Rack Adaptor. (L3 FA2100 and Honeywell HFR5-V CVR Aircraft Rack Adapter. On-Aircraft)
L3 Comm FDR & CVR FA5000 FDR & CVR.	FDS40-0247	ARINC-757 CVR Rack Adaptor. (L3 FA2100 and Honeywell HFR5-V CVR Aircraft Rack Adapter. On-Aircraft)
L-3 SRVIVR 1493100-1XXX 1493199-3XXX	FDS40-0260	L3 Com SRVIVR CVR Power Cable (On-Aircraft)
Universal 1605 CVDR 1606 CVR	FDS40-0258 (Power)	UASC 1605 1606 series CVR Download Power Cable (On-Aircraft)